

THIS DOCUMENT AND THE INFORMATION CONTAINED THEREIN IS PROPRIETARY TO CARRIER CORPORATION AND SHALL NOT BE USED OR DISCLOSED TO OTHERS, IN WHOLE OR IN PART, WITHOUT THE WRITTEN AUTHORIZATION OF CARRIER CORPORATION.

KIT PART NO.	PART. NO.	MODEL DESCRIPTION
76-02066-00	98-02751	X4 7700 DOMESTIC, RAIL EDITION, EXPORT

KIT PART NO.	PART. NO.	MODEL DESCRIPTION
76-02066-00	98-02751	X4 7700 DOMESTIC, RAIL EDITION, EXPORT

DECAL KIT, ENGLISH - CHINESE

NOTES:

- I.O COMPLETE INSTALLATION INCLUDES AND IS NOT LIMITED TO:
 - I.I UNIT INSTALLATION I.I.I MOUNTING HOLE PLUG INSTALLATION

DESCRIPTION

FUEL TANKS (22" DIAMETER)

LED LIGHT BAR INSTALLATION INSTRUCTIONS

DECAL KIT, ENGLISH - ARABIC

- I.2 BATTERY INSTALLATION, INCLUDING DRAIN HOSE
- 1.3 COMPLETION OF PRE-DELIVERY INSPECTION (PDI)PER MODEL
- I.3.I UNIT PREP AND INITIAL ADJUSTMENTS I.3.2 CHECKLIST
- I.3.3 UNIT RUN IN PER PDI CHECKLIST
- 1.2.4 WARRANTY REGISTRATION CARD SUBMITTAL
- 1.3.5 PERFORM MICRO DATA DOWNLOAD
- 1.4 DEFROST LINE ROUTING AND CLAMPING
- 1.5 FUEL LINE CONNECTIONS TO UNIT 2.0 THE TRAILER OR BOXCAR STRUCTURE MUST BE EVALUATED BY THE TRAILER OR BOXCAR MANUFACTURER TO DETERMINE ITS ABILITY TO WITHSTAND THE LOADS IMPOSED BY THE
 - UNIT OVER ITS SERVICE LIFE. CARRIER TRANSICOLD DOES NOT CONVEY ANY ENDORSEMENT OR WARRANTY FOR THE TRAILER'S OR BOXCAR'S STRUCTURAL INTEGRITY. WEIGHTS:

CROSS REFERENCE INDEX

INSTALLATION

DRAWING NO.

98-02750

98-03246

98-03333

98-03348

KIT NO.

76-00988-XX

76-02000-00

76-02033-00

76-02033-03


- X4 7700 REFER UNIT (WET, LESS BATTERY) : TBD
- 3.0 UNIT MOUNTING SURFACES OF THE TRAILER OR BOXCAR THAT CONTACT THE UNIT MOUNTING PADS MUST BE UNI-PLANAR TO WITHIN 0.13 [3] TO PREVENT DISTORTION OF THE UNIT AND/OR TRAILER.
- 3.1 MOUNTING STUDS MUST NOT PROTRUDE MORE THAN 3.0 INCHES FROM THE TRAILER OR BOXCAR SURFACE FOR PROPER INSTALLATION OF THE MOUNTING HOLE PLUGS.
- 4.0 TRAILER OR BOXCAR SURFACES THAT CONTACT THE UNIT MOUNTING GASKET SHOULD NOT PROTRUDE MORE THAN 0.19 [5] ABOVE THE PLANE DEFINED BY THE MOUNTING PAD SURFACES TO ENSURE PROPER AIR SEAL.
- 5.0 ALL DIMENSIONS SHOWN ARE IN INCHES, WITH THE METRIC CONVERSIONS IN [MILLIMETERS].
- 6.0 PRE-DELIVERY INSPECTION AND WARRANTY REGISTRATION DOCUMENTS ARE SHIPPED WITH UNIT AND ARE LOCATED IN THE SIDE DOOR POCKET WITH UNIT MANUAL AND SCHEMATIC.

CONTENTS	SHEET
GENERAL INFORMATION	
SWING RADIUS	2
UNIT DIMENSIONAL DATA	2
EVAP. BACK PANEL: TRAILER OR RAIL	3
TRAILER OR BOXCAR PREPARATION	4
UNIT INSTALLATION	5
UNIT LIFTING LOCATION	5
BATTERY INSTALLATION	6
CHUTE DIMENSIONAL INFORMATION	7
BOTTOM PANEL INSTALLATION	8

SHEET

SEE SEPARATE PARTS LIST

А	INITIAL RELEASE	NOV 2022	LT-NS	ТМ		ECN1161724	
SYM	REVISION RECORD	DATE	ВҮ	ENGR.	M . E .	NPCA NO.	



IMPERIAL INCH FORMAT:
UNLESS OTHERWISE SPECIFIED
DIMENSIONS ARE IN INCHES WITH
METRIC CONVERSIONS IN [MILLIMETERS]


INSTALLATION INSTRUCTIONS X4 7700 TRAILER & RAIL


SUPERSEDES:

98-02751

PART CLASSIFICATION: US EAR99

SHEET OF






SUBMISSION OF THESE DRAWINGS OR DOCUMENTS

PART CLASSIFICATION: US EAR99

SUPERSEDES:








APPLY CARRIER OVAL AFTER UINT IS FASTENED TO TRAILER AND MOUNTING HOLE IS PLUGGED.

TWO PLACES

- SEE NOTE 8.0



-4.00[102] BULKHEAD


OF BULKHEAD)


(TOP OF FLOOR TO BOTTOM


SEE NOTE 13 FOR OPTIONAL

BULKHEAD CONFIGURATION

INSIDE OPENING







JNII INSIALLAIION



- I.O PREPARE THE BODY TO RECEIVE THE UNIT. DIMENSIONS FOR EVAPORATOR OPENING AND MOUNTING STUD LOCATIONS AND LENGTHS CAN BE FOUND ON SHEET 4 OF THIS DRAWING.
- 2.0 REMOVE WIRE TIES HOLDING DEFROST DRAIN HOSES, COOLANT OVERFLOW TUBE, AND FUEL LINES. PLACE LINES WHERE THEY WILL NOT BE CAUGHT BETWEEN THE UNIT FRAME AND THE MOUNTING SURFACE.
- 3.0 OPEN SIDE DOORS TO ALLOW ACCESS TO MOUNTING STUD LOCATIONS ON UNIT. 3.1 PLUG UNUSED HOLE WITH HOLE PLUG.
- 4.0 INSTALL BATTERY ACCORDING TO INSTRUCTIONS ON SHEET 6. TO PREVENT ACCIDENTAL ELECTRIFICATION, DO NOT REMOVE TERMINAL COVERS OR CONNECT TERMINALS UNTIL AFTER UNIT IS COMPLETELY INSTALLED.
- 5.0 PREPARE THE UNIT FOR LIFTING: STANDING ON A LADDER OR WORK-STAND, MAKE A CLOSE-UP INSPECTION OF THE CONDITION AND INTEGRITY OF THE LIFTING EYES, THEN HOOK LIFTING APPARATUS (LIFTING SPREADER BAR WITH SUFFICIENT CAPACITY TO SUPPORT UNIT AND BATTERY) THROUGH THE LIFTING EYES.

WARNING: HOOKS OR CLEVISES SHOULD BE EQUIPPED WITH A LOCKING FEATURE. LIFT POINT SHOULD BE CENTERED OVER THE UNIT'S CENTER OF GRAVITY (SEE SHEET 2). WHILE LIFTING THE UNIT INTO PLACE, INSTALLER SHOULD NOT BE UNDER OR IN PROXIMITY OF THE SUSPENDED UNIT.


UNIT INSTALLATION:

- 6.0 RAISE THE UNIT AND INSTALL IN THE BODY OPENING. ENSURE THAT ALL EIGHT STUDS ARE FULLY ENGAGED IN THE UNIT FRAME. PLACE WASHER (ITEM 70) AND LOCK-NUT (ITEM 45) ON EACH OF THE 8 STUDS. (NOTE: THE LOWER CENTER STUD MUST BE ACCESSED FROM THE FRONT OF THE UNIT.) SNUG THE NUTS, THEN EVENLY TIGHTEN ALL EIGHT TO 60 FT-LB/81.6 NM USING A TORQUE WRENCH. REMOVE LIFTING APPARATUS.
- 7.0 INSTALL MOUNTING HOLE PLUGS (ITEM 92) IN UNIT FRAME WHERE MOUNTING STUDS ARE LOCATED. ENSURE ALL 9 LOCATIONS HAVE HOLE PLUGS. IF THE MOUNTING STUD EXCEEDS THE MAXIMUM LENGTH OF 3.0 INCHES FROM THE TRAILER OR BOXCAR SURFACE, A PRE-CUT SLIT IS INCORPORATED IN THE MOUNTING HOLE PLUG TO ALLOW THE STUD TO PROTRUDE THROUGH THE PLUG. (SEE SHT.4).
- 8.0 ROUTE DEFROST DRAIN HOSES DOWN THE FRONT OF THE TRAILER OR BOXCAR AND CLAMP TO FRONT WALL USING 2 CLAMPS (ITEM 15) AND 2 THREAD FORMING SCREWS (ITEM 30) FOR EACH DRAIN HOSE. CUT HOSE TO PROPER LENGTH (APPROXIMATELY 3.00[76.2] ABOVE 5th-WHEEL PLATE ON TRAILER) AND INSTALL KAZOOS (ITEM 90) ON THE HOSES.
- 9.0 INSTRUCTIONS FOR FUEL LINE CONNECTION ARE SUPPLIED WITH THE FUEL TANK KIT. INSTRUCTIONS FOR LIGHT BAR INSTALLATION ARE INCLUDED WITH THE LIGHT BAR KIT.

AFTER INSTALLATION

- 10.0 PERFORM PRE-DELIVERY INSPECTION. COPIES OF COMPLETED CHECKLIST SHOULD BE SUPPLIED TO SELLING DEALER AND CUSTOMER.
- OPERATE UNIT IN CONTINUOUS RUN WITH REAR DOORS OPEN (MANUAL) MODE. REFER TO THE PRE-DELIVERY INSPECTION FORM SUPPLIED WITH UNIT FOR THE RECOMMENDED LENGTH OF TIME. PERFORM FINAL INSPECTION ON UNIT. RUN- IN SET UP SHOULD BE "PER PDI SHEET".
- 12.0 IMPORTANT: PRIOR TO FINAL DELIVERY TO CUSTOMER, WARRANTY REGISTRATION MUST BE COMPLETED. ONE COPY SHOULD BE PROVIDED TO THE CUSTOMER, ONE COPY TO THE SELLER, AND THE FINAL COPY MUST BE SENT TO CARRIER CARRIER TRANSICOLD. IN-SERVICE DATE MUST BE STAMPED ON THE UNIT IN THE PROPER LOCATION (SERIAL NUMBER PLATE) TO ACTIVATE WARRANTY COVERAGE.
- 13.0 OPTIONAL BULKHEAD CONFIGURATION: HOLE PATTERN OR OPEN AREA FOR RETURN AIR FLOW MUST TOTAL AT LEAST 2.75 FT² OF AIR PASSAGE. HOLE PATTERN OR OPEN AREA MUST BE RECESSED SO THAT CARGO LOADED AGAINST BULKHEAD WILL NOT OBSTRUCT AIR PASSAGE OPENINGS. PERFORATED BULKHEADS, THAT MEET THESE REQUIREMENTS, MAY BE INSTALLED TIGHT WITH FLOOR.

A INITIAL RELEASE ΤM II NOV 2022 LT-NS ECN1161724 REVISION RECORD ENGR. M.E NPCA NO.



IMPERIAL INCH FORMAT: UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES WITH TITLE METRIC CONVERSIONS IN [MILLIMETERS]

 (\odot)


INSTALLATION INSTRUCTIONS X4 7700 TRAILER & RAIL


DRAWING NO. 98-02751

PART CLASSIFICATION: US EAR99

sheet 5 of

SUPERSEDES:





SCALE 0.200


BATTERY INSTALLATION PROCEDURE FOR UNTS SHIPPED WITHOUT BATTERY

INSTALL BATTERY INTO
UNIT WITH POSITIVE (+) TERMINAL
TOWARDS THE REAR.

SCALE 0.200

<u>ITEMS SUPPLIED IN BATTERY KIT</u>

(PARTS IN POLY BAG AND/OR ATTACHED TO BATTERY TRAY)



UNITS SUPPLIED WITH BATTERY INSTALLED

- I.O CUT WIRE TIE(S) THAT HOLD BATTERY CABLES TO UNIT FRAME.
- 2.0 CONNECT RED BATTERY CABLE TO THE POSITIVE (+) BATTERY TERMINAL; CONNECT BLACK CABLE TO NEGATIVE (-) BATTERY TERMINAL (USE OF CORROSION INHIBITOR IS RECOMMENDED).
- 3.0 POSITION TERMINAL COVERS SUPPLIED WITH CABLES OVER TERMINALS.
- 4.0 INSTALL DRAIN HOSE (ITEM 6) TO BARB ON BOTTOM OF BATTERY TRAY USING CLAMP (ITEM 5). ROUTE AND CLAMP HOSE TO UNIT DRAIN LINE USING WIRE TIES (ITEM 55).

UNITS SUPPLIED WITHOUT BATTERY INSTALLED

I.O USE THE FOLLOWING INFORMATION TO CORRECTLY SELECT THE BATTERY PERFORMANCE NEEDED FOR REFRIGERATION UNITS.

GROUP SIZE: GROUP 31
VENT LOCATION: SIDE VENT
VOLTS: 12 VOLTS DC
AMPERAGE: MINIMUM 700 COLD CRANKING AMPS @ 0°F
MINIMUM 545 COLD CRANKING AMPS @ -20°F

- NOTE: WHEN SELECTING A SPECIFIC BRAND OF BATTERY, ALWAYS ENSURE THAT THE BATTERY CHOSEN IS RATED AT 0°F (0 DEGREES FAHRENHEIT) AND NOT 0°C (0 DEGREES CELSIUS). FAILURE TO USE THE PROPER BATTERY SIZE WILL RESULT IN REDUCED BATTERY LIFE AND A NO-START CONDITION.
- 2.0 CUT WIRE TIE HOLDING THESE PARTS IN THE BATTERY TRAY AND REMOVE PARTS.
 PLACE BATTERY IN TRAY WITH NEGATIVE (-) TERMINAL TO THE FRONT OF THE UNIT AND INSTALL CURBSIDE L-BRACKET AND BOLT. CONNECT BATTERY CABLES (THE USE OF A CORROSION INHIBITOR ON THE TERMINALS IS RECOMMENDED); RED CABLE TO POSITIVE (+) TERMINAL, BLACK CABLE TO THE NEGATIVE (-) TERMINAL. CABLES SHOULD BE ROUTED AS SHOWN. VERIFY BATTERY CABLES DO NOT CONTACT THE COMPRESSOR, SHARP EDGES, ETC. TIGHTEN TERMINAL CONNECTORS SECURELY.
- 3.0 LAY HOLD-DOWN BRACKET OVER THE TOP OF BATTERY. INSTALL J-BOLT HOOK INTO SLOT ON L-BRACKETS AND THROUGH SLOT ON HOLD DOWN BRACKET. SECURE J-BOLT WITH WASHERS AND NUTS AS SHOWN. SECURELY TIGHTEN THE NUTS TO PREVENT MOVEMENT OF THE BATTERY.
- 4.0 POSITION TERMINAL COVERS SUPPLIED WITH CABLES OVER TERMINALS.
- 5.0 INSTALL DRAIN HOSE (ITEM 6) TO BARB ON BOTTOM OF BATTERY TRAY USING CLAMP (ITEM 5). ROUTE AND CLAMP HOSE TO UNIT DRAIN LINE USING WIRE TIES (ITEM 55).

A INITIAL RELEASE

REVISION RECORD



IMPERIAL INCH FORMAT:
UNLESS OTHERWISE SPECIFIED
DIMENSIONS ARE IN INCHES WITH
METRIC CONVERSIONS IN [MILLIMETERS]

INSTALLATION INSTRUCTIONS
X4 7700 TRAILER & RAIL

98-02751 SHEET 6 OF

PART CLASSIFICATION: US EAR99

RAWING NO.

SUPERSEDES: PART CLASSIFICAT

NG CLASSIFICATIC




OR DISCLOSED TO OTHERS, IN WHOLE OR IN PART, WITHOUT THE WRITTEN AUTHORIZATION OF CARRIER CORPORATION.

SUBMISSION OF THESE DRAWINGS OR DOCUMENTS DOES NOT CONSTITUTE PART PERFORMANCE OR ACCEPTANCE OF CONTRACT

NOTE: BULKHEAD AND AIR CHUTE SHOWN ARE OPTIONAL FEATURES.
FOR BEST AIR CIRCULATION AND PRODUCT PROTECTION,
CARRIER TRANSICOLD HIGHLY RECOMMENDS THE USE OF
BULKHEADS AND AIR CHUTES. CONTACT YOUR DEALER OR
CARRIER TRANSICOLD FOR RECOMMENDATIONS.

TRANSITION & CHUTE DETAILS



A INITIAL RELEASE II NOV 2022 LT-NS ECN1161724 THIRD ANGLE - PROJECTION ENGR. NPCA NO. REVISION RECORD М.Е.

IMPERIAL INCH FORMAT:
UNLESS OTHERWISE SPECIFIED
DIMENSIONS ARE IN INCHES WITH
METRIC CONVERSIONS IN [MILLIMETERS]


INSTALLATION INSTRUCTIONS
X4 7700 TRAILER & RAIL

DRAWING NO. 98-02751 sheet 7 of

PART CLASSIFICATION: US EAR99 SUPERSEDES:


PROPRIETARY TO CARRIER CORPORATION AND SHALL NOT BE USED OR DISCLOSED TO OTHERS, IN WHOLE OR IN PART, WITHOUT THE WRITTEN AUTHORIZATION OF CARRIER CORPORATION.

SUBMISSION OF THESE DRAWINGS OR DOCUMENTS DOES NOT CONSTITUTE PART PERFORMANCE OR ACCEPTANCE OF CONTRACT




BOTTOM PANEL INSTALLATION

NOTES: I.O INSTALL (5) MOUNTING ANGLES (ITEM #80), WITH RIVNUTED FLANGE DOWN, TO FRAME USING SUPPLIED SCREWS (ITEM #75). TORQUE SCREWS TO 96 IN-LBS, KEEPING THE BOTTOM OF THE ANGLES FLUSH AND PARALLEL TO THE BOTTOM OF THE FRAME. 2.0 SLIDE (5) OPENINGS IN THE BOTTOM PANEL OVER THE (5) REAR MOUNTING ANGLES ON THE FRAME AND SECURE BOTTOM PANEL TO OTHER (5) MOUNTING ANGLES USING SUPPLIED SCREWS (ITEM #175). TORQUE SCREWS SECURELY TO 96 IN-LBS.



А	INITIAL RELEASE	NOV 2022	LT-NS	TM		ECNII617
SYM	REVISION RECORD	DATE	ВҮ	ENGR.	M.E.	NPCA NO



IMPERIAL INCH FORMAT:	TITLE
UNLESS OTHERWISE SPECIFIED	
DIMENSIONS ARE IN INCHES WITH	
METRIC CONVERSIONS IN [MILLIMETERS]	

INSTALLATION	INSTRUCTIONS
X4 7700 TRAI	LER & RAIL

		_
ING NO.	REV	N.G
98-02751	Δ	DRAWI
SHEET 8 OF	/ \	

PART CLASSIFICATION: US EAR99 SUPERSEDES: